Fakir
HAUSGERÄTE

Minia

Izgara & Tost Makinesi
Grill & Sandwich Maker

Instruction Manual
Kullanım Kılavuzu

Giriş

Uzun yıllar sorunsuz çalışması için tasarlanan ve üretilen Fakir Minia Izgara ve Tost Makinesini satın aldığınız için teşekkür ederiz.
Benzer ürünleri kullanmaya alışık olabilirsiniz, ancak kullanma kılavuzunu okumak için lütfen zaman ayırınız. Bu kılavuz satın almış olduğunuz üründen en iyi performansı almanız için hazırlanmıştır.

Güvenlik önemlidir

Kendi güvenliğiniz ve diğerlerinin güvenliği için ürünü çalıştırmadan önce kullanma kılavuzunu okuyunuz. Bu kılavuzu ilerideki kullanımlar için güvenli bir yerde saklayınız.

Güvenlik uyarıları

Elektrikli bir cihaz kullanılırken, aşağıdaki önlemler her zaman alınmalıdır. Yangın, elektrik çarpması ve kişisel yaralanmaları engellemek için;

- Cihazın altında belirtilen akım gücünün, evinizdeki akım gücüyle eşit olmasına dikkat ediniz.
- Sıcak yüzeylere dokunmayınız, tutamakları kullanın. Dış yüzeyler aşırı sıcak olabilir.
- Elektrik çarpmalarına karşı kabloyu, fişi veya cihazı su veya başka bir sıvıya daldırmayınız. Lütfen temizlik talimatlarını inceleyiniz.
- Cihazınız çocuklar tarafından veya çocukların yakınında kullanılacağı zaman mutlaka bir yetişkin tarafından gözetlenmelidir.
- Cihaz kullanılmadığı zamanlarda veya temizlik sırasında mutlaka prizden çekilmelidir. Soğumasını bekleyiniz.
- Cihazı iyice temizlemek için pişirme plakalarını kaldırılabilir ve yıkayabilirsiniz.
- Cihazı asla suya daldırmayınız. Cihazı nemli bir bezle temizleyebilirsiniz.
- Cihazın elektrik kablosunun sıcak pişirme plakalarına temas etmemesine özen gösteriniz.
- Eğer bir uzatma kablosu kullanacaksanız, uzatma kablosunun iyi durumda olması, toprak bağlantısına sahip olması ve kablo telinin en aşağı 1 mm çapında olması gerekmektedir.
- Cihazı kullanacağınız zaman elektrik kablosunu tamamen açınız. Elektrik kablosunu cihazın alttaki kablo yuvasına sarmadan önce iyice soğumasını bekleyiniz.
- Arızalı, kendisi veya kablosu hasar görmüş cihazlar kesinlikle kullanılmamalıdır.
- Uygun olmayan ek malzemelerin kullanılması yangına, elektrik çarpmasına, yaralanmalara sebep olabileceği gibi garantinin bozulmasına da sebep olacaktır.
- Cihaz dış mekanlarda kullanılmamalıdır.
- Şebeke kablosunun keskin, sivri veya sıcak yerlerle temasına engel olunuz.
- Cihazınızı asla fırın, ocak gibi sıcak yerlere yakın yerleştirmeyiniz.
- Cihazın fişini prizden çıkarmak için asla kablosundan çekmeyiniz.
- Cihazı belirtilen amacın dışında başka bir işlev için kullanmayınız.
- Büyük hacimli yiyecekler, metal folyolu paketler veya diğer uygun olmayan malzemeler, yangın veya elektrik çarpmalarına neden olabileceği için asla kullanılmamalıdır.
- Cihazınız kullanım sırasında yanabilecek malzemelerle çevrelenirse veya bu maddeler cihazın içerisine yerleştirilirse yangına neden olabilir.
- Cihazınız kullanım sırasında yalnız bırakılmamalıdır.
- Cihazınızın arıza yapmasını önlemek için sık sık temizleyiniz. Kullanılmadığında veya temizlik yapılacağı zaman mutlaka fişi prizden çekiniz.
- Cihazı kuru yüzeylerde kullanınız.
- Sert deterjanları veya bulaşık süngerlerini, yüzeye zarar verecekleri için, kullanmayınız.
- Cihaz sadece ev kullanımı için tasarlanmıştır. Kullanma talimatlarına uygun olmayan ticari kullanımlar garanti kapsamı dışındadır.

NOT!

"BU KULLANMA KILAVUZUNU İLERİDEKİ KULLANIMLAR İÇİN SAKLAYINIZ."

Ürün Parçalarının Tanıtımı

1. Tutma Sapı
2. Üst pişirme plakası
3. Alt pişirme plakası
4. Sıcaklık kontrol lambası
5. Sıcaklık kontrol düğmesi
6. Sağ ayak
7. Sol ayak
8. Yağ akıntı ağzı

NOT!

Cihaz 180° açılabilme özelliğine sahiptir. Pişirme plakaları çıkarılabilir ve çift yönlüdür.

KULLANIM ÖNCESİ

- Alt ve üst tablayı hafifçe yağlayınız.
- Tost makinenizin fişini takınız.
- Üst tablayı sapları tutarak yatay hale getiriniz.
- Sıcaklık ayar düğmesini seçtiğiniz konuma alınız.
- Cihaz sıcaklık seviyesine ayarlandığında, kırmızı ışık yanacaktır.
- İstenilen sıcaklık seviyesine ulaşıldığında kırmızı ışık sönecektir.
- Isınma süresi yaklaşık 5-10 dk.dır. Bu sürede pişirilecek yiyeceklerinizi hazırlayabilirsiniz.
- Tost makineniz ilk ısınmada koku ve hafif duman çıkarabilir. Bu durum normaldir.

NOT!

Cihazın yüzeyi kullanım sırasında çok sıcak olacağından bu yüzeylere dokunmayınız ve kullanım sırasında daha dikkatli olunuz.

UYARI!

Eğer cihaz yüzeyinde herhangi bir çatlak var ise, elektrik çarpmasını engellemek için cihazı kullanmayınız.

NOT!

İlk kullanımda cihazdan biraz duman ve koku çıkabilir, bu durum yeni maddeler ısıtıldığı için normaldir ve bir süre sonra yok olacaktır.

KULLANIM

Ön Isıtma

- Cihazı fişe takınız, gösterge ışığı yanacaktır.
- Gösterge ışığı yeterli sıcaklık seviyesine ulaşınca sönecektir. (Ortalama 8-10 dk.)
- Gösterge ışığının sönmesi ile ön ısıtma süresi tamamlanmış olacaktır ve yiyeceklerinizi plakalara yerleştirebilirsiniz.

Plakaların Değiştirilmesi

- Elektrik kablosunu prizden çekiniz.
- Cihazın soğumuş olduğundan emin olunuz.
- Cihazı tamamen açarak (180°) düz hale getiriniz.
- Tespit mandalını aşağı doğru iterek pişirme plakasını kaldırınız.
- Aynı işlemi ikinci plaka için de tekrarlayınız.

Plakaların Takılması

- Pişirme plakalarını arka kenarından cihaza yerleştiriniz.
- Pişirme plakasını indiriniz ve yavaşça tespit mandalının altına bastırınız.

Temizlik ve Bakım

- Izgaranızı, yiyeceklerin yapışmış kısımlarının kalmaması için, her kullanımdan sonra mutlaka temizleyiniz.
- Cihazı temizlemeden önce, ızgarayı kapatın ve fişini prizden çekiniz. Temizlemeye başlamadan önce, ızgaranızın ılık duruma gelmesini bekleyiniz. Makine hafif ılıkken, daha kolay temizlenir.
- Cihazı tamamen açınız ve tespit mandalına bastırarak pişirme plakalarını çıkarınız.
- Pişirme plakalarını sıcak sabunlu suda, üzerine yapışan artıkları yumuşatmak üzere yaklaşık beş dakika bekletiniz.
- Pişirme plakalarını sıcak sabunlu suda ya da bulaşık makinesinde temizleyiniz.
- Cihazınızın dış yüzey kısmını nemli bir bez ile silebilirsiniz. Zımpara etkili temizlik malzemesi ya da sert deterjanları kullanmayınız.

NOT!

Pişirme plakaları, yapışmaz yüzeyle kaplanmıştır. Sert siliciler kullanmayınız. Yapışmaz kaplamanın üstüne sprey sıkmayınız. Bu pişirme tepsisindeki yapışmaz yüzeyin performansını etkileyecektir.

Saklama

- Cihazınızın fişini prizden çekiniz. Izgaranın tamamen soğumasını bekleyiniz.
- Yerden tasarruf sağlamak amacıyla cihazı dik olarak muhafaza edebilirsiniz.

INTRODUCTION

Thank you for purchasing Fakir Minia Grill and Sandwich maker which has been designed and manufactured to give you many years of trouble-free service.
You may already be familiar with using a similar product, but do please take time to read these instructions - they have been written to ensure you get the very best fromyour purchase.

Safety is Important

To ensure your safety and safety of others, please ensure you read safety instructions before you operate this product. Keep this information in a safe place for future referances.

SAFETY INSTRUCTIONS

Do not touch hot Top cover. Use handles or knobs. Surfaces become extremely hot.

- Check if the mains voltage indicated on the bottom of the appliance corresponds to the mains voltage in your home before you connect the appliance.
- Do not touch hot surfaces. Use the handles. The surfaces can be extremely hot.
- To prevent against electrical hazards, do not immerse cord , plug or toaster in water or other liquid, See instructions for cleaning.
- Close supervision is necessary when any appliance is used by children or near children.
- Always unplug appliance from outlet when not in use and before cleaning. Allow to cool before cleaning and handling.
- For cleaning, you can remove the cooking plates.
- Never immerse the appliance in water. You can clean it with a damp cloth.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- If you need to use an extension cord, verify that it is in proper condition, earthed and that the wires are at least 1 mm.
- Fully unwind the cord when you use the appliance. Let the appliance cool down properly before you wind the cord around the hooks in the base.
- Do not operate any appliance with a damaged cord or plug, Do not replace that if the power or plug is damaged. After appliance malfunctions, or is dropped or damaged in any manner. Return the appliance to an authorized service facility for examination, repair or electrical or mechanical adjustment.
- Do not use any unauthorized attachments. This will void the warranty and may cause fire, electric shock or injury.
- Do not use outdoors. Do not place toaster on or near a hot gas or electric burner or a heated oven.
- To disconnect, grasp plug and remove from outlet. Never unplug by pulling the cord.
- Do not use toaster for other than intended use.
- Oversized foods. Metal foil packages or utensils must not be inserted in the machine as they may involve a risk of fire or electric shock.
- Do not operate machine near flammable materials such as curtains, wall fabric, etc. to prevent fire.
- To avoid possibility of fire, do not leave toaster unattended during use.
- Always use the grill on a dry surface.
- Avoid the use of scouring pads or harsh detergents as they may damage the surface.
- Your appliance is designed for personal use. The manufacturer will not be liable nor will the warranty remain in the effect in case of any inappropriate Professional which does not meet the specifications of the use manual.

Specifications

1. Handle
2. Upper cooking plate
3. Lower cooking plate
4. Temperature pilo light
5. Temperature Control
6. Right hinge
7. Left Hinge
8. Draining grove

Before first time usage

- Unpack your new Health Grill and remove all extra fittings such as plastic wrappers and cable clamps meant for protection during transportation.
- Before starting up your new Health Grill, check the contents for completeness and any visible damage.
- Read the directions for use carefully.
- Put the appliance on a firm, level surface with a completely open as if you were peforming a double side cooking operation.
- Remove the cooking plates and wash them separetly in hot soapy water.
- Rinse and dry cooking plates.
- Find a place for the health grill where it can be used safely.

NOTICE!

The temperature of accessible surfaces may be high when the appliance is operating. Do not touch surfaces, always use the handle.

WARNING!

If the surface is cracked, switch off the appliance to avoid the possibility of the electric shock.

NOTICE!

During the initial use, some smoke can appear, this is normal for new heating elements and will cease with further use.

OPERATION

Preheating

- Plug in the appliance.The indicator light is on.
- Let your appliance heat up for a little until the pilot light goes off. (8-10 min.)
- Your appliance is ready for grilling.

Removing the Cooking Plates

- Unplug the appliance.
- Let it cool down before you touch it.
- Completely open your appliance as if you were peforming a double side cooking operation.
- Push the fixing clip and remove the plate.
  Do this operation for the second plate.

Reassembling the Cooking Plates

- Place the rear edge of the cooking plates on the appliance.
- Lower the grilling plates onto the appliance and press them down under the fixing clip.

Care and Cleaning

- Always clean your Grill toaster after each use to prevent a build up of bake-on foods.
- Before cleaning, turn the power off at the power outlet and then remove the plug. Allow your health Grill to cool before cleaning. The unit is easier to clean when slightly warm.
- Completely open your appliance as if you were performing a double side cooking operation and remove the cooking plates by pressing on the fixing clips.
- Soak the cooking plates in hot soapy water for five minutes to loosen any residues that might have caked on it.
- Clean the cooking plates in hot soapy water or put them in dishwasher.
- You can clean the surfaces of the unit with a damp cloth. Do not use any scouring cleaning agents or materials.

NOTICE!

The cooking plates are coated with a non-stick surface, do not use abrasives. Do not use spray on non-stick coatings as this will affect the performance of non-stick surface on the cooking plate.

STORAGE

- Switch off the appliance and unplug from the power outlet.
  Allow the Grill to fully cool.
- To save space, you can store the appliance in upright position.
- Put the appliance in vertical position.

NOT / NOTES

YEŞİL NOKTA
ÇEVKO
RoHS
COMPLIANT